

MOUNTING THE TELOS LIGHT CONTROLLER

To mount the Telos Light controller use suitable screws and wall plugs to secure the controller to the wall. We recommend rounded head screws. Leave 2.5mm of the screw shaft proud of the wall to allow the head to go into the rear of the controller.

Use the above template to align the screws so they match the holes in the controller.

TELOS

